



# PSOC™ 4 Liquid level sensing (LLS) training Customer training workshop (CTW)

December 2025



# Prerequisites

- Basic hands-on with ModusToolbox™
- Basic understanding of PSOC™ 4 devices
- Install or update the following on your PC:
  - ModusToolbox™ tools package v3.6.0
  - ModusToolbox™ Eclipse IDE 2025.4.0
  - ModusToolbox™ programming tools 1.5
  - ModusToolbox™ CAPSENSE™ and Multi-sense pack

# Table of contents

1	Liquid level sensing	4
2	Development ecosystem	12
3	Tuning and calibration	18
4	Lab 1: Liquid level sensing (LLS) factory calibration	23
5	Lab 2: Liquid level sensing (LLS) foam rejection calibration	26

# Table of contents

<b>1</b>	<b>Liquid level sensing</b>	<b>4</b>
<b>2</b>	Development ecosystem	12
<b>3</b>	Tuning and calibration	18
<b>4</b>	Lab 1: Liquid level sensing (LLS) factory calibration	23
<b>5</b>	Lab 2: Liquid level sensing (LLS) foam rejection calibration	26


# Liquid-level sensing

# CAPSENSE™ technology with inductive and liquid sensing

## Infineon PSOC™ 4 with Multi-sense


### CAPSENSE™ – Capacitive sensing

#### Self-capacitive sensing




- **CSD** – Infineon's proprietary self-capacitance sensing method
- Measures capacitance of a single electrode
- User touch increases the capacitance of the electrode

#### Mutual capacitive sensing




- **CSX** – Infineon's proprietary Mutual-capacitance sensing method
- Measures capacitance between two electrodes
- User touch decreases capacitance between electrodes

### Inductive sensing



- **ISX** – Infineon's proprietary Inductive sensing method
- Measures inductance of sensor coil
- Deflection of metal decreases inductance of the electrode

### Liquid sensing



- **LLS** – Infineon's proprietary liquid sensing method
- Detects presence and level of liquid without contacts
- Reliable sensing and rejects false signals such as foam mist and droplets

# Applications/Use cases

## – Humidifiers

- Liquid level calculation helps estimate the number of hours the humidifier can run before refilling is required

## – Coffee makers

- It enables the estimation of the number of cups that can be brewed before the water reservoir needs to be refilled



## – Robot mopping machines

- Help estimate the number of cleaning cycles that can be completed before the water tank needs to be refilled
- Prevents machine damage due to low water levels


## – Pet water-bowl

- Detects the low and empty levels to control the motor that pumps the water through the fountain




## Basic concept

- Liquid level sensing (LLS) involves measuring the increased capacitance when water is near the sensor



(a)

Capacitance and electric field of a capacitive liquid level sensor






(b)

Added capacitance ( $C_L$ ) when the liquid approaches a capacitive sensor






# Standard liquid level sensing

- Algorithm is based on signal changes relative to a static baseline measured during manufacturing
- Place equally sized sensors along the length of the container
- Drawback: Lower accuracy




# ML-based approach used by LLS

- Algorithm uses an ML trained model to detect liquid level



# Advantages



# Table of contents


1	Liquid level sensing	4
2	<b>Development ecosystem</b>	<b>12</b>
3	Tuning and calibration	18
4	Lab 1: Liquid level sensing (LLS) factory calibration	23
5	Lab 2: Liquid level sensing (LLS) foam rejection calibration	26

# Development ecosystem

# Development resources


Components required for developing and tuning an LLS design:

- Liquid in a container
- LLS sensor
- PSOC™ 4 device
- Software tools




# Sensor pattern

- Array of sensor segments equally spaced from the top to the bottom of the container
- Sensor Designer tool to generate a pattern



# Sensor designer tool

- Inputs: Sensor dimensions, tank details (overlay stack-up)
- Output: DXF file





## Tank details (overlay stack-up)

- Input thickness and dielectric constant of the layers of the tank
- Estimate achievable liquid capacitance
- Indicate if good liquid sensing performance is expected



# Table of contents

1	Liquid level sensing	4
2	Development ecosystem	12
3	<b>Tuning and calibration</b>	<b>18</b>
4	Lab 1: Liquid level sensing (LLS) factory calibration	23
5	Lab 2: Liquid level sensing (LLS) foam rejection calibration	26


# Tuning and calibration

# Tuning and calibration

- CAPSENSE™ performance tuning
  - Sensors must be tuned as per guidelines for optimal performance
- CAPSENSE™ LLS factory calibration
  - Required for the ML model-based algorithm to work accurately
  - Explained in lab 1
- CAPSENSE™ LLS foam rejection calibration
  - Explained in lab 2

# Foam rejection

- Detects liquid level accurately even in the presence of foam
- Enable 'foam rejection' in CAPSENSE™ configurator
- Perform foam rejection calibration before the regular calibration procedure



# Environmental effects

## – Temperature fluctuations

- Can have a significant impact on the capacitance of the system
- Calibrate your system for your typical liquid temperature

## – Mechanical variations

- Static variations are compensated for during manufacturing with the calibration operation
- Dynamic variation is caused by changes during operation
  - Ensure that there are no air bubbles present in the adhesive
  - Ensure that the mechanical design is sufficient to maintain accurate sensor alignment

# Table of contents

1	Liquid level sensing	4
2	Development ecosystem	12
3	Tuning and calibration	18
4	<b>Lab 1: Liquid level sensing (LLS) factory calibration</b>	<b>23</b>
5	Lab 2: Liquid level sensing (LLS) foam rejection calibration	26

# Lab 1: Liquid level sensing (LLS) factory calibration



# PSOC™ 4000T Multi-Sense Prototyping Kit [CY8CPROTO-040T-MS]

The CY8CPROTO-040T-MS PSOC™ 4000T Multi-Sense Prototyping Kit allows you to evaluate the features of the PSOC™ 4000T device.

The kit also comes with the following expansion boards:

- A flex PCB with nine sensors, offering a full-scale liquid-level reading of 120 mm
- A touch-over-metal (ToM) Keypad-4 board with 14 mm coils
- A touch-over-metal (ToM) Keypad-2 board with 22 mm coils
- A hover-touch board with four 10 mm buttons that can detect a touch from a distance of 10 mm

## QUICK START GUIDE

## PSOC™ 4000T Multi-Sense Prototyping Kit

CY8CPROTO-040T-MS

### Kit contents

1. PSOC™ 4000T Multi-Sense control board
2. Inductive keypad - 4 expansion board
3. Inductive keypad - 2 expansion board
4. Liquid level sensor expansion board
5. Plastic container for liquid level sensing demonstration
6. CAPSENSE™ hover touch expansion board
7. USB-A to USB-C cable
8. Quick start guide (this document)



[www.infineon.com/CY8CPROTO-040T-MS](http://www.infineon.com/CY8CPROTO-040T-MS)

# Table of contents

1	Liquid level sensing	4
2	Development ecosystem	12
3	Tuning and calibration	18
4	Lab 1: Liquid level sensing (LLS) factory calibration	23
5	<b>Lab 2: Liquid level sensing (LLS) foam rejection calibration</b>	<b>26</b>

# **Lab 2: Liquid level sensing (LLS) foam rejection calibration**



# **Thank you!**

## **Stay tuned for more trainings...**

Join with us on our mission to drive decarbonization and digitalization Together.



# Revision history

Document revision	Date	Description of change
**	2025-12-12	Initial release.

